


**Annunciator C172**

Displays various warnings of aircraft systems



**Chronometer C172**

Displays Local & Zulu Time, Battery Volts, Outside Temperature and provides a timer



**Flaps Indicator (30 Degrees) for C172**

Shows the status of the Flaps



**Flaps Indicator (40 Degrees) for C172**

Shows the status of the Flaps



**Exhaust Gas Temp and Fuel Flow**

Displays the Exhaust Gas Temperature (Deg F) and Fuel Flow (Gals/hr)



**Oil Temp & Press**

Displays the Oil Temperature (Deg F) and Pressure (PSI) for the Engine



**RPM for the Engine or Prop**

Displays the RPM for the Prop or Engine



**Vacuum and Battery Amps**

Displays the Vacuum (Suction) and Battery Amps



**Fuel Quantity Dual**

Displays the fuel qty for each fuel tank



## Panel Builder 3 C172 - Instrument Reference

---



### Altimeter with Barometric Pressure adjustment

Displays altitude in feet

---



### Heading Indicator Vacuum C172

Displays the current heading with bug for autopilot

---



### Turn Rate and Slip Indicator

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).