

## Panel Builder 3 - Gazelle Instruments



### Clock/Chronometer Gazelle

Clock with Chronometer functions



### Warning Panel Gazelle

Displays various warnings and system information



### Volts of Battery

Displays Volts for the Battery



### Engine Temperature

Displays Engine Temperature in hundreds of Deg C



### Oil Temperature of Engine

Displays Oil Temperature of Engine in Deg C



### Rotor and Turbine RPM

Displays RPM of Rotor and Turbine



### Torque of Helicopter Engine

Displays the torque of the helicopter engine in percent



### Fuel Tank

Displays Fuel available in tenths of liters



### Heading, ADF and NADIR/VOR display

Displays the direction to current ADF and NADIR/VOR and magnetic heading (slaved to Gyro)

## Panel Builder 3 - Gazelle Instruments

---



### Airspeed Indicator for Gazelle

Displays airspeed in km/h

---



### Altimeter with Barometric Pressure adjustment

Displays altitude in meters

---



### Artificial Horizon Gazelle

Displays attitude of helicopter

---



### Artificial Horizon Gazelle (Standby)

Displays attitude of helicopter

---



### Radio Altimeter with Decision Height Bug

Displays altitude in meters above ground level. Ability to set decision height with lit LED when decision height is reached.

---



### Vertical Speed Indicator Gazelle

Displays the rate at which the helicopter climbs or descends in hundreds of meters per minute