

## Panel Builder 3 - Huey Instrument

---

### Annunciator Square (Configurable)



Displays various system information

---


### Clock Huey



Displays an Analog Clock

---

### DC Load of Main Generator



Displays DC Load of Main Generator

---

### DC Load of Stby Generator



Displays DC Load of Standby Generator

---

### DC Volt Meter



Displays DC Volts

---

### EGT Display



Displays the exhaust gas temperature in Deg C

---

### Engine Oil Pressure Display



Displays the engine oil pressure in psi

---


### Engine Oil Temperature Display



Displays the engine oil temperature in Deg C

---

### Gas Producer RPM (N1)




Displays RPM of Gas Generator in Percent

## Panel Builder 3 - Huey Instrument



### Rotor and Turbine RPM

Displays RPM of Rotor and Turbine



### Torque Pressure Display

Displays the torque pressure in psi



### Transmission Oil Pressure Display

Displays the transmission oil pressure in psi



### Transmission Oil Temperature Display

Displays the transmission oil temperature in Deg C



### Fuel Pressure Display

Displays the fuel pressure in psi



### Fuel Tank Display

Displays the fuel tank contents



### Course Deviation Indicator

Displays LOC/VOR course and glideslope deviation with OBS knob



### Magnetic Compass

Displays helicopter magnetic heading



### Radio Compass Indicator

Displays the direction to current NDB and VOR and magnetic heading (slaved to Gyro)

## Panel Builder 3 - Huey Instrument

---



### Airspeed Indicator

Displays airspeed in knots

---



### Altimeter with Barometric Pressure adjustment

Displays altitude in feet

---



### Altimeter with Barometric Pressure adjustment

Displays altitude in feet

---



### Attitude Indicator

Displays attitude of helicopter

---



### Radio Altimeter (0 to 1500 feet)

Displays altitude in feet above ground level.

---



### Turn Rate and Slip Indicator Huey

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).

---



### Vertical Speed Indicator Huey

Displays the rate at which the helicopter climbs or descends in feet per minute

---