

Panel Builder 3 - Spitfire Instruments



Analog Clock Spitfire

Displays an Analog Clock




Gear Position Indicator Spitfire

Displays Positon of Landing Gear



Trim Indicator Spitfire

Displays Positon of the Elevator Trim



Voltage of Battery

Displays Voltage for Battery



Boost Gauge Spitfire (alternate version)

Show boost pressure




Boost Gauge Spitfire (alternate version)

Show boost pressure



Boost Gauge Spitfire

Show boost pressure



Oil Pressure Spitfire

Displays the oil pressure



Oil Temperature Spitfire

Displays the oil temperature in Deg C

Panel Builder 3 - Spitfire Instruments



Radiator Temperature Spitfire

Displays the radiator temperature in Deg C



RPM of Engine

Displays the RPM of the engine



Fuel Spitfire

Displays current available fuel quantity in gallons



Airspeed Indicator Spitfire Knots

Displays airspeed in miles per hour



Altimeter with Barometric Pressure adjustment Spitfire

Displays altitude in feet



Artificial Horizon Spitfire

Displays attitude of aircraft



Directional Gyro Spitfire

Displays aircraft heading



Turn Rate and Slip Indicator Spitfire

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).



Vertical Speed Indicator Spitfire

Displays the rate at which the aircraft climbs or descends in feet/minute